





1240 SERIES LENS REPLACEMENT

<p>Remove the two philips head screws that attach the lamp clip to the trim.</p>	
<p>Remove old lens.</p>	
<p>With a pair of pliers gently press bullet catches out of trim until they no longer interfere with the travel of the lens.</p>	
<p>New lens is inserted 90 degree to trim and hinged down into place.</p>	
<p>With pliers gently press bullet catches back into position. If catches are loose in trim it may be necessary to apply instant glue such as Loctite or Crazy glue to secure catches in trim.</p> <p>Align lamp clip so that back of clip aligns with back of trim and reattach with philips head screws.</p>	



**SPECIALTY LIGHTING
INDUSTRIES, INC.**

1306 DORIS AVENUE OCEAN, NJ 07712 800.462.7812 732.517.0800 FAX 732.517.0971 www.specialtylightingindustries.com

These specifications subject to change without notice. ©2/08