


# ULTRIM PLASTER FRAME INSTALLATION

1. Provide necessary blocking and threaded rods secured to structure, see below or submittal sheet.
2. Provide rough opening in ceiling for plaster frame housing, see cut sheet for dimensions.
3. Install plaster frame by fastening rods or turnbuckles, at appropriate intervals to provide proper support, to the continuous linear 1/4-20 bolt receptacles located on the top of the extruded aluminum plaster frame.
4. Prepare power supply feed.
5. Install gypsum wall board (sheet rock) around plaster frame, using factory edge against plaster frame, if possible. Fasten GWB to frame using perforated metal tabs, included.
6. Caulk seam between sheet rock and plaster frame with silicone vinyl acrylic compound. Skim coat over plaster frame and sheet rock, using screed edge on inside edge of plaster frame as a guide for spreading tool. Sand and paint.
7. Hook up the power feed supply to the fixture, our fixture has leads, 10' of 10 ga stranded copper wire. Install fixture by means of machine bolts threaded into the cage nuts provided with the mounting brackets that are welded to the plaster frame.
8. Install lamps, test with power, install lenses.



**SPECIALTY LIGHTING  
INDUSTRIES, INC.** ©2004

1306 DORIS AVENUE OCEAN, NJ 07712 800.462.7812 732.517.0800 FAX 732.517.0971 [www.specialtylightingindustries.com](http://www.specialtylightingindustries.com)

These specifications subject to change without notice.